3009-1

DANGER: Causes severe skin burns and eye damage.

Do not breathe mist/vapors/spray. Wash face, hands, and any exposed skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection.

FIRST AID: IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable for breathing. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/Doctor.

Store locked up. Dispose of contents and container in accordance with all local, regional, and national regulations.

Contains [CAS#]: Sodium metasilicate [6834-92-0], dipropylene glycol monomethyl ether [34590-94-8].





www.chemexindustries.com • 3 Chattanooga, Irvine, CA 92620 Phone: 714-832-8441 • Email: barry@chemexindustries.com

SELF RINSING COLUMN TO THE SELF RINSING EVAPORATOR COIL CLEANER

No Rinsing Required

Deodorizes, Cleans and Treats Air-Conditioning Systems for Maximum Efficiency

Retards Future Dirt Accumulation
Eliminates Slime in Condensate Areas

DANGER: CAUSES SEVERE SKIN BURNS AND EYE DAMAGE. FOR PROFESSIONAL USE ONLY. KEEP OUT OF REACH OF CHILDREN. SEE SIDE PANELS FOR ADDITIONAL PRECAUTIONS.

NET CONTENTS: 1 U.S. GALLON (3.78 LITERS)

3009-1 DIRECTIONS FOR USE:

(Window Units, Small Central Units)

- Read entire label & Safety Data Sheet before use.
- 2. Dilute with up to 6 parts water.
- 3. Shut unit off.
- 4. Spray coil thoroughly using a coarse spray to avoid misting.
- 5. Wait 5 minutes and resume normal operation.
- No rinsing is required when condensation is present. If condensation is not expected, rinse with water.

(Commercial Systems, Air Handling Units)

Dilute with up to 6 parts water before use. If possible leave air-flow on during application. Spray intake side of coil with coarse spray until saturated to the run off point. (Suction of system will cause complete coil penetration.) Refuse and contamination will drain as condensate. If it is not possible to leave air-flow on during application, spray coil thoroughly and turn air on immediately after application. If condensation is not expected, rinse with water.